



Features

- Precise Measurements Accuracy is 0.1 % of full scale; repeatability is 0.02% of full scale and hysteresis is 0.1% of full scale or less
- Reliability Linear dials, span micro-adjust and zero reference adjust allow component replacement and simplify recalibration. Extra high quality corrosion-resistant materials of construction - 5 year warranty on materials of construction!
- Reliable Operation 120 % fall scale pressure with no caliration shift and 200% full scale pressure without damage
- Extreme Stability Inherent temperature compensation from -25° F (-32° C) to 125° F (+52° C)
- Ease of Operation Easy reading high resolution dial in soft green and white with a polished mirror band to eliminate parallax error
- <u>Various Sizes/Ranges</u> dial sizes of 7", 8.5", 12" and 16" are available. Pressure ranges from vacuum to 10,000 PSIG
- Options mounting flanges, special fittings, custom scales and logos



Product Description

The 3D Precision Test Gauge (PTG) is certified for industrial and laboratory pressure transfer measurement in the U.S. and worldwide. Incorporating 3D Instruments well known expertise in test gauge design and application, the PTG provides unsurpassed long-term accuracy. The dial face design comes directly from 3D experience with the practical use of high resolution pressure calibration in the laboratory and in the field.

Utilizing a highly sensitive Ni-Span C bourdon tube, the PTG is virtually unaffected by temperature variations. This obsoletes the need for an expensive add-on temperature compensation device. The bourdon tube material offers a superior spring rate varying only 0.02% from -25° F (-32° C) to 125° F (+52° C).

With the F'TG, there is no requirement for preliminary pressure cycling. All materials utilized are selected to be corrosion resistant. All gauges are supplied with a bleed port. Bronze bushings are used to ensure low friction and long term precision in extreme applications involving dust, vibration and temperature variation.

The gauge dial uses the 3D Instruments anti-glare soft green color with anti-parallax mirror band and white outer ring for maximum user resolution. This approach has proven practical advantages for technicians and engineers.

All 3D Instruments Precision Test Gauge dials, for pressure ranges from vacuum to 10,000 PSI, are linear and for the same pressure range are interchangeable in the field. The advantage of using the Ni-Span C bourdon tube and the resulting low hysteresis is that the PTGs are not individually matched to a non-linear dial. The compelling benefit here is that this makes field repair and calibration not only a possibility but a relatively easy task performed with exactness and facility by instrument technicians.

The combination of sophisticated pressure measurement technology, robust design and high quality materials makes the Precision Test Gauge from 3D Instruments the ideal choice for your demanding high accuracy pressure measurement applications.

GENERAL SPECIFICATIONS

Accuracies:

0.1% of full scale

Includes all effects of repeatability, linearity and hysteresis. Accuracy obtained by calibration with pressure standards traceable to NIST. Calibration points - 12 points upscale and 12 points downscale

Repeatability:

0.02% of full scale

Sensitivity:

0.1% of full scale or less

Proof Pressure:

120% of maximum rated pressure

Burst Pressure:

200% of maximum rated pressure

Process Connection:

1/4" NPT female - other sizes are avalable including $^{1}/_{4}$ " NPT male and $^{1}/_{2}$ " NPT male

Dial Sizes:

7" (178nun) 8.5" (216 mm) 12" (305 mm) 16" (406 nun)

Needle Movement - Full Scale:

310°dial arc

Ambient/Service Temperature:

-25° F (-32° C) to 125° F (+52° C)

Operating Media:

Any media suitable for contact with Ni-Span C, 300 series stainless steel and

Buna-N

Materials of Construction:

Case: Aluminum Bourdon Tube: Ni-Span C Process Connection: 316 SS

Crystal: Lexan

Resolution Table:			
Standard		Sub-	Gauge
Range	Increments	Divisions	Diameter
0-15 psi	750	.02	7, 8.5, 12
0 15 psi	1500	.01	16
30 psi	600	.05	7, 8.5, 12
50 por	1500	.02	16
60 psi	600	10	7, 8.5, 12
00 ps.	1200	.05	16
100 psi	1000	.1	All
150 psi	750	.2	7, 8.5, 12
150 psi	1500	1	16
200 psi	1000		All
300 psi	600	.5	7, 8.5, 12
500 psi	1500	2	16
400 psi	800	- -	All
500 psi	1000	.2 .5 2 .5 .5 .5	All
600 psi	600	1	7, 8.5, 12
000 psi	1200	ŝ	.,,
800 psi	800	1	All
1000 psi	1000	î	All
1500 psi	750	2	7, 8.5, 12
F	1500	1	16
2000 psi	1000		All
3000 psi	600	2 5 2 5 5	7, 8.5, 12
2000 pm	1500	2	16
4000 psi	800		All
5000 psi	1000	5	All
6000 psi	600	10	7, 8.5, 12
F	1200	5	16
8000 psi	800	10	All
10000 psi	1000	10	All
10000 psi	VACUUM	10	
15-0 psi	750	.02	7, 8.5, 12
15 5 psi	1500	.01	16
30-0 in / hg	600	.05	7, 8.5, 12
	1500	.02	16
800-0 mm / hg	800	1	All
		-	

ORDERING INFORMATION

123 4567 8

PART NUMBER: 25 X 1 X XX X X 1 XXX

Example: 25516-23E21 8.5" Precision Test Gauge with 0-100 PSI range, black case

front flange, back 1/4" NPT female pressure fitting

Product Description: 0.1% accuracy Precision Test Gauge

① Type of Gauge:

1: Compound scale: combination vacuum and positive pressure scales - 5 ranges available from: 30" Hg-0-30 PSI to -30" Hg-0-300 PSI

2: Vacuum scale: -30" Hg - 0

5: Positive Pressure Scale: available in ranges from 0-15 PSI to 0-10000 PSI

2 Accuracy of Gauge:

1: 0.1% of span

Size of Gauge:

9: 7" dial size **6:** 8.5" dial size **7:** 12" dial size **8:**16" dial size

⊕ Pressure Ranges Codes: (Codes 48, 23, 24 25 & 26 can be obtained as compound ranges w/vacuum to: 30" Hg - use code: 1 in # 1 above)

15: 30"Hg - 0 (Note: Vacuum gauge - must be used in conjunction with a 2 in #1 above. Add: AAU option Code as well in #8 for scale: -15 psi - 0)

48: -30" Hg-0-30 PSI **24**: 0-150 PSI 33: 0-3,000 PSI **28**: 0-600 PSI **15**: 0-15 PSI **25**: 0-200 PSI **53**: 0-800 PSI 34: 0-4,000 PSI 21: 0-30 PSI **26**: 0-300 PSI **29:** 0-1,000 PSI 35: 0-5,000 PSI **51:** 0-400 PSI 31: 0-1,500 PSI 36: 0-6,000 PSI **22:** 0-60 PSI 23: 0-100 PSI **27**: 0-500 PSI 32: 0-2,000 PSI 37: 0-8,000 PSI

S Process Connection: (Note: standard pressure fitting code is E - 1/4" NPT female)

B: $\frac{1}{4}$ " NPT male **C**: $\frac{1}{2}$ " NPT male **D**: $\frac{1}{8}$ " NPT female **E**: $\frac{1}{4}$ " NPT female

a Code: 2 is the standard fitting/flange configuration for the 8.5", 12", and 16" dial sizes)

1: Bottom Fitting/Front Flange
2: Back Fitting/Front Flange
3: Bottom Fitting/Wall Mount Brackets
5: Bottom Fitting/No Flange*

*Not available on 8.5", 12" or 16" dial sizes

7 Case Type:

1: Black aluminum case

® Option Codes and Accessories: (Leave #8 blank if no options are required)

ISO:Metric Scale in kPa or MPaISOD:Dual Scale - PSI and kPa or MPa (PSI is on outer ring)ISK:Metric Scale in Kg/cm²ISKD:Dual Scale - PSI and Kg/cm² (PSI is on outer ring)ISB:Metric Scale in BarISBD:Dual Scale - PSI and Bar (PSI is on outer ring)

AAE: Throttle screw

AAV: "Maximum Pressure" pointer

3D Instruments, LP

2900 E. White Star Ave., Anaheim, California 92806 USA

Phone: (714) 399-9200

Internet: www.3dinstruments.com E-mail: cs@3dinstruments

38: 10,000 PSI